Modules for workshop presses FP-Model

Guard at the front pneumatics up & down
Läntmännen 502547

Fixed guard behind the press
Provinor 502510



Press flange with ø40 rotations stop
Eagle Burgmann 502561



Press plate with guided columns
Keune & Lauber 502405

KTP600 Electrical press control

Press bed standard

Manually movable press bed
Benzlers 502520

Hydraulically movable press bed
Keune & Lauber 502405

2-Hand operation

Electrical foot operation

Foot operation with wire cable

Modules for workshop presses EP-Model

Press plate with guided columns
Keune & Lauber 502405

Press bed standard

Press flange with ø40
rotations stop
Eagle Burgmann 502561

KTP600 Electrical press control

2-Hand operation

Electrical foot operation

Foot operation with wire cable